



NB Gear stick surround installation guide

Remove the lower centre console to get to the plastic mount which holds the gear stick gaiter in place (4 screws) then cut the top up-stand off as marked below, this is so your new surround can sit flush. Then remove the factory gear surround. Once this is done reassemble the centre console and mount your new gear surround with the 3M tape mounted to the underside.

